



STEPS TO FOLLOW

1. Fix the Pulleys at the end of the track ( E and B ) , see figure 6. Put the cable around the pulleys , insert in the groove of the wheels.
2. Close the doors and adjust the cable length, see fig 4.
3. Following the cable length adjustment , insert the excess cable into the connector as illustrated in the fig 4 and then tighten it up with allen key and socket screw (F) supplied .
4. When you have achieved the hook eye shape with the cable (F) block it between washers and plate (A/1) with the help of socket screws. Repeat it for the other side plate A/2 , see fig 6.

