



BASE

Instruction Manual

KILLIS

Contents

Before use	2
Safety symbols	2
Safety instructions	3
EU declaration of conformity	4
Operation	5
Technical specifications	5
Base Unit	6
Warranty	7

BEFORE USE

Please read carefully the instruction manual before use.

WARNING: Operators shall be adequately instructed on the use of the BASE charging unit.

This machine is suited for the commercial use, e.g. in hotels, schools, hospitals, factories, shops, offices, and rental companies.

WARNING: This machine is for indoor use only. It shall be stored indoors only.

SAFETY SYMBOLS



WARNING!
Risk of injury!



WARNING!
Danger of electric shock!



Do not dispose of power tools into household waste! According to the European Directive 2012/19/EU on waste electrical and electronic equipment (WEEE) and its incorporation into national law, power tools that are no longer suitable for use must be separately collected and sent for recovery in an environmental- friendly manner.

Old appliances contain valuable materials that can be recycled. Please arrange for the proper recycling of old appliances. Batteries, oil, and similar substances must not enter the environment. Please dispose of your old appliances using appropriate collection systems.

SAFETY INSTRUCTIONS



WARNING! **Risk of injury!**

- This machine is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge.
- Any different use from that indicated in this manual could constitute a danger, therefore, it must be avoided.
- Every part of the apparatus must be correctly assembled before using it.
- Ensure that the socket conforms to the apparatus' plug.
- Ensure that the voltage indicated corresponds with the power that is intended to connect the apparatus to
- Specialised personnel must always carry out maintenance and repairs; any damaged part must be substituted with original spare parts.
- It is forbidden to carry out changes to the apparatus. Tampering could cause fires and damages even lethal to the user and the forfeiture of the guarantee.
- The manufacturer declines any responsibility for damages caused to people or things due to non-compliance with these instructions or if the apparatus is unreasonably used.



WARNING! **Danger of electric shock!**

- Do not ever pull or lift the apparatus through the electrical cable.
- Always remove the plug from the current socket before undertaking any type of intervention on the apparatus or if it is left unattended or within children or people's reach not quite conscious of their own actions.
- Regularly control the feeding cable
- looking for damages, cracks or ageing. Substitute the cable before using it further.
- If the feeding cable is damaged it must be substituted by the manufacturer or by its after sales service or in any case by a similarly qualified person, thus preventing any possible risk.



EN

EU Declaration of Conformity

We declare that the machine described below complies with the relevant basic safety and health requirements of the EU Directives, both in its basic design and construction as well as in the version put into circulation by us. This declaration shall cease to be valid if the machine is modified without our prior approval.

Product: Robotic Vacuum Charging Station
Type: Base /-6-Station Charging Terminal Stand

Relevant EU Directives
2014/35/EU

Applied Harmonized Standards
EN 60335-1:2012/A13 2017

KILLIS Ltd.
1a Orgreave Road, Dore House Industrial Estate,
Handsworth, Sheffield, S13 9LQ. UK.

A handwritten signature in black ink, appearing to read 'T. Killi', is positioned above the printed name and title.


Tibor J. Killi
Managing Director

INSTRUCTIONS FOR USE


The Base unit is used for charging robotic vacuum cleaners in a fixed location, or as a mobile unit.

1. The Base unit is to be located in any dry internal location and must never be exposed to damp, moisture or any liquid spillages.
2. Do not locate the Base unit directly against any heat source. A minimum of a 1 meter gap is required.
3. The Base unit requires 230 volt power supply.
4. Do not stack items or drape objects on top or over the Base unit.
5. Once the Base unit is plugged in to an external power supply, it is ready to accept robot vacuums for charging.
6. Place an individual robot onto a charging dock located on each charging shelf. See robot vacuum instructions.
7. The robot will indicate charging is in process. Refer to manufacturers instructions.
8. Once fully charged the robot will stop charging. See robot manufacturers instructions.
9. When leaving the Base unit for longer periods of time it is recommended, as with all electrical appliances, to switch off the mains power.
10. The Base unit is fitted with a braked wheel. Apply the brake when stationary.


TECHNICAL INFORMATION



220-240 V
50/60 Hz




Class 1
(Insulation Class only
applies to the Base unit)



Up to 5 m

BASE UNIT



WARRANTY

The warranty terms published by the relevant sales company are applicable in each country. We will repair potential failures of your appliance within the warranty period free of charge, provided that such failure is caused by faulty material or defects in manufacturing. In the event of a warranty claim please contact your dealer or the nearest authorised Customer Service centre. Please submit the proof of purchase.



KILLIS Ltd.

1a Orgreave Road, Dore House Industrial Estate,
Handsworth, Sheffield, S13 9LQ. UK.